


































Original	Substitut	Original	Substitut
	Power		Power
	TXT		Text
	EPG		Guide
	Input		AV
	Menu		Menu
	[>]		Format
	Lang		Dual
	Subt		Subt
	i		Info
	Exit		Exit
	Q.Menu		D. Menu
	Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok

Original	Substitut	Original	Substitut
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	[+]		3D
	P+		Ch +
	P-		Ch -
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7





Original		Substitut		Original		Substitut	
	8		8				
	9		9				
	0		0				
	TV		TV/R				
	↔		Pre Ch				

