







































































| Original | Substitut | Original | Substitut |
|---|-----------|---|--------------------------------|
|  | Power |  | Power |
|  | Stop |  | Stop / Hold |
|  | Pause |  | Pause / Step / Freeze |
|  | Rec |  | Rec / Rec Mode |
|  | << |  | << / Tune- |
|  | Play |  | Play / Slow |
|  | >> |  | >> / Tune+ |
|  | [[[/]]] |  | Zoom / Size |
|  | * |  | D.Menu / Top |
|  | [<>] |  | Picture / Format |
|  | Tv Guide |  | Guide / EPG / -/- |
|  | Search |  | Shift + Red / Netflix / Search |
|  | Sources |  | AV / Input / RDS |
|  | Smart Tv |  | Smart / List |
|  | Home |  | Menu / Home |
|  | Exit/Tv |  | Exit / Cancel / Clear |
|  | Red |  | Red / Netflix / Search |
|  | Green |  | Green / APP / Repeat |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | i+/Info |  | Info / Angle |
|  | Options |  | Setup / OPT / Options |
|  | Up |  | Up |
|  | Left |  | Left |
|  | OK |  | OK |
|  | Right |  | Right |
|  | Back |  | Back / Return |
|  | Down |  | Down |
|  | Multiview |  | Display / Media |
|  | Vol+ |  | Vol+ |
|  | List |  | Shift + Smart / List |
|  | CH+ |  | CH+ / Page+ |
|  | Vol- |  | Vol- |
|  | Mute |  | Mute / Dimmer |





| Original | Substitut | Original | Substitut |
|----------|---------------|----------|-----------|
| CH- | CH- / Page- | | |
| 1 | 1 | | |
| 2 | 2 | | |
| 3 | 3 | | |
| 4 | 4 | | |
| 5 | 5 | | |
| 6 | 6 | | |
| 7 | 7 | | |
| 8 | 8 | | |
| 9 | 9 | | |
| Subtitle | Subtitle / EQ | | |
| 0 | 0 | | |
| Text | Text / Goto | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

