







































































Original	Substitut	Original	Substitut
	Power		Power
	Open / Close		Eject / Surround
	Display		Display / Media
	Audio		Audio / Lang I/I
	Subtitle		Subtitle / EQ
	Angle		Info / Angle
	Setup		Setup / OPT /
	Menu		Menu / Home
	Top Menu		D.Menu / Top
	Multi Dial-		Down
	Multi Dial+		Up
	Enter		OK
	Function		Fav / Marker / PC
	Video Adjust		Picture / Format
	FL Dimmer		Mute / Dimmer
	Jog Mode 1		Left
	Jog Mode 2		Right
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Previous		I<< / Preset-
	Next		>>I / Preset+
	REV		<< / Tune-
	FWD		>> / Tune+
	Return		Back / Return
	<II Step/Slow		CH- / Page-
	Step/Slow II>		CH+ / Page+
	Search Mode		Red / Netflix / Search
	1		1
	2		2
	3		3
	Clear		Exit / Cancel / Clear
	4		4
	5		5





Original	Substitut	Original	Substitut
6	6	6	6
+10	+10	GUIDE EPG	Guide / EPG / -/--
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - BAT 0	0
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PROGRAM	Program	TV/RADIO PROGRAM	TV/Radio /
LAST MEMORY	Last Memory	+ VOL	Vol+
CONDITION MEMORY	Condition Memory	VOL -	Vol-

Original	Substitut

