










































| Original  | Substitut | Original  | Substitut      |
|---|-----------|---|----------------|
|      | Standby   |      | Power          |
|      | Auto      |      | Smart          |
|      | Tv/Radio  |      | TV/R           |
|      | Mute      |      | Mute           |
|      | 1         |      | 1              |
|      | 2         |      | 2              |
|      | 3         |      | 3              |
|      | 4         |      | 4              |
|      | 5         |      | 5              |
|      | 6         |      | 6              |
|     | 7         |     | 7              |
|    | 8         |    | 8              |
|    | 9         |    | 9              |
|    | 0         |    | 0              |
|    | -/--      |    | Shift + Guide  |
|    | Back      |    | Back           |
|    | Vol+      |    | Vol +          |
|    | Vol-      |    | Vol -          |
|    | CH+       |    | Ch +           |
|    | CH-       |    | Ch -           |
|    | Nicam/A2  |    | Options        |
|    | Aspect    |    | 3D             |
|    | Display   |    | Info           |
|    | Up        |    | Up             |
|    | Down      |    | Down           |
|    | Right     |    | Right          |
|    | Left      |    | Left           |
|   | OK        |   | Ok             |
|  | Menu      |  | Menu           |
|  | Exit      |  | Exit           |
|  | Source    |  | AV             |
|  | P.Mode    |  | Shift + Format |
|  | S.Mode    |  | Shift + Dual   |
|  | Sleep     |  | Sleep          |





| Original   | Substitut  |
|--|--|
|  Fav      |  Pre Ch       |
|  Fav-     |  Shift + Ch - |
|  Fav+     |  Shift + Ch + |
|  Hold     |  Shift + AV   |
|  EPG      |  Guide        |
|  Text     |  Text         |
|  Lang     |  Dual         |
|  Subtitle |  Subt         |
|  Index    |  List         |
|  Reveal   |  Eject        |
|  Subpage  |  D. Menu      |
|  Media  |  Media      |
|  Size   |  Format     |
|  Play   |  Play       |
|  Pause  |  Pause      |
|  <<     |  <<         |
|  >>     |  >>         |

| Original   | Substitut  |
|--|--|
|  Rec    |  Rec    |
|  Stop   |  Stop   |
|  I<<    |  I<<    |
|  >>I    |  >>I    |
|  Red    |  Red    |
|  Green  |  Green  |
|  Yellow |  Yellow |
|  Blue   |  Blue   |

