









































































Original	Substitut	Original	Substitut
On/Off	 Power	Menu Right	 Right
Mute	 Mute	Display	 Shift + Info
Update	 List	Menu Off	 Exit
Reveal	 Dual	Menu Down	 Down
Txt Stop	 Stop	Back	 Back
Info	 Info	Volume+	 Vol +
Subt.List	 Subt	Chan.Up	 Ch +
Sleep Timer	 Sleep	Volume-	 Vol -
Return TV	 TV/R	Chan.Down	 Ch -
Menu video	 Options	1	 1
Text	 Text	2	 2
Txt Expand	 Eject	3	 3
TV/AV	 AV	4	 4
Menu	 Menu	5	 5
Menu Up	 Up	6	 6
Menu Left	 Left	7	 7
OK Enter	 Ok	8	 8



Original	Substitut	
9		9
Guide -/-- 1.		Guide
0/10		0
Disp	 + 	Shift + AV
Aft/Caf	 + 	Shift + 3D
2.Fav P/C 2.		Pre Ch
Red		Red
Green		Green
Yellow		Yellow
Rotate Text		D. Menu
Mix Scan		Smart
Store Text	 + 	Shift + Text
Bright+ Mode		3D
Browse		Media
Blue		Blue
Tone-	 + 	Shift + Vol -
Contrast+	 + 	Shift + Ch +

Original	Substitut	
Tune-		<<
Tune+		>>
Contrast-	 + 	Shift + Ch -
Surround	 + 	Shift + Red
4.# 16:9		Format
Nicam/Mono	 + 	Shift + Green
Color+ P.Std	 + 	Shift + Format
Level L	 + 	Shift + Yellow
Level R/Woofer	 + 	Shift + Blue
Audio+		>>
Tone+	 + 	Shift + Vol +
Audio-		<<

