


























































| Original | Substitut | Original | Substitut |
|---|-----------|---|--------------------|
| PP | PP |  | Back / Return |
|  | Power |  | Power |
| 1 | 1 |  | 1 |
| 2 | 2 |  | 2 |
| 3 | 3 |  | 3 |
| 4 | 4 |  | 4 |
| 5 | 5 |  | 5 |
| 6 | 6 |  | 6 |
| 7 | 7 |  | 7 |
| 8 | 8 |  | 8 |
| 9 | 9 |  | 9 |
| P<P | P<P |  | Fav / Marker / PC |
| 0 | 0 |  | 0 |
| -- | -- |  | Guide / EPG / -/-- |
|  | Menu [M] |  | Menu / Home |
|  | Info [i] |  | Info / Angle |
|  | I-II |  | Audio / Lang I/II |

| Original | Substitut | Original | Substitut |
|---|------------------|---|-----------------------------|
|  | Mute |  | Mute / Dimmer |
|  | Left |  | Left |
|  | Up |  | Up |
|  | Right |  | Right |
|  | OK |  | OK |
|  | Down |  | Down |
|  | V - |  | Vol- |
|  | V + |  | Vol+ |
|  | P - |  | CH- / Page- |
|  | P + |  | CH+ / Page+ |
|  | Red / Sound |  | Red / Netflix / Search |
|  | Red / Sound |  | Sound / Title |
|  | Green / Picture |  | Green / APP / Repeat |
|  | Green / Picture |  | Picture / Format |
|  | Yellow / Feature |  | Yellow / YouTube / Repeat |
|  | Blue / Install |  | Blue / Prime Video / Random |
|  | Text |  | Text / Goto |





| Original | Substitut |
|-----------------|---|
| [≡o] | TIMER SLEEP Sleep / Timer |
| Hold | HOLD Stop / Hold |
| [≡X] | CLEAR EXIT CANCEL Exit / Cancel / Clear |
| Mix / PIP Swap | LIST SMART Smart / List |
| PIP / Size | SIZE ZOOM Zoom / Size |
| PIP Down / [≡?] | PRESET- I<< / Preset- |
| PIP Up / Index | PRESET+ >>I / Preset+ |
| [TV] | PROGRAM TV/RADIO TV/Radio / |
| [AV] | RDS AV INPUT AV / Input / RDS |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

| Original | Substitut |
|----------|-----------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

