







































































| Original | Substitut | Original | Substitut |
|--|--|--|--|
|  Power |  Power |  List |  List |
|  Sleep |  Sleep |  Back |  Back |
|  Mute |  Mute |  Menu |  Menu |
|  Mode |  Smart |  CH + |  Ch + |
|  1 |  1 |  CH - |  Ch - |
|  2 |  2 |  Vol + |  Vol + |
|  3 |  3 |  Vol - |  Vol - |
|  4 |  4 |  Up |  Up |
|  5 |  5 |  Left |  Left |
|  6 |  6 |  OK |  Ok |
|  7 |  7 |  Right |  Right |
|  8 |  8 |  Down |  Down |
|  9 |  9 |  FAV |  Pre Ch |
|  0 |  0 |  EPG |  Guide |
|  Nicam/A2 |  Dual |  Info |  Info |
|  TXT / Mix |  Text |  Exit |  Exit |
|  TV / Radio |  TV/R |  Red |  Red |



