










































Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	<<		<< / Preset-
	>>		>>  / Preset+
	EQ		Subtitle / EQ
	Zoom		Zoom / Size
	TV-Mode		TV/Radio /
	Setup		Setup / OPT /
	L/R		Text / Goto
	Input		AV / Input / RDS
	Menu		Menu / Home
	Up		Up
	Left		Left
	Enter		OK
	Right		Right
	Reset		Exit / Cancel / Clear
	Down		Down
	Return		Back / Return
	Vol+		Vol+
	Treb+		CH+ / Page+
	Vol-		Vol-
	OSD		Display / Media
	Treb-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6





Original	Substitut
<b>7</b>	AUX - HDD 7
<b>8</b>	USB 8
<b>9</b>	BLUETOOTH 9
<b>10+</b>	GUIDE EPG Guide / EPG / -/--
<b>0/10</b>	HDMI - BAT 0
<b>P/N</b>	PC FAV MARKER Fav / Marker / PC
<b>REPEAT</b>	APP REPEAT Green / APP / Repeat
<b>SUB</b>	YouTube REPEAT A-B Yellow / YouTube / Repeat
<b>+ SUB</b>	Prime Video RANDOM Blue / Prime Video / Random
<b>SLOW</b>	SHIFT + SLOW Play /
<b>A1</b>	SHIFT + TV 1
<b>A2</b>	SHIFT + DVD 2
<b>B1</b>	SHIFT + CD - STB 3
<b>B2</b>	SHIFT + VIDEO 4
<b>C1</b>	SHIFT + TAPE 5
<b>C2</b>	SHIFT + TUNER 6
<b>D1</b>	SHIFT + AUX - HDD 7

Original	Substitut
<b>D2</b>	SHIFT + USB 8 Shift + 8
<b>E1</b>	SHIFT + BLUETOOTH 9 Shift + 9
<b>E2</b>	SHIFT + GUIDE EPG Shift + Guide / EPG / -/--
<b>E3</b>	SHIFT + HDMI - BAT 0 Shift + 0
<b>E4</b>	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC

