




















Original	Substitut
	Power
	Power Tv
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	Tv/Radio
	Pre-CH
	Vol+
	Vol-
	Mute

Original	Substitut
	CH+
	CH-
	CH List
	Tv Portal
	Menu
	EPG
	Tools
	Info
	Return
	Exit
	Up
	Down
	Right
	Left
	Enter
	Red
	Green





Original	Substitut	Original	Substitut
 Yellow	 Yellow		
 Blue	 Blue		
 Text	 Text		
 Audio	 Dual		
 SUB	 Subt		
 Rec	 Rec		
 <<	 <<		
 Pause	 Pause		
 Play	 Play		
 Stop	 Stop		
 >>	 >>		

