









































































































































Original	Substitut	Original	Substitut
 Power	 Power	 Menu/[≡i]	 Menu
 Tv/Input	 AV	 P↔P	 Pre Ch
 Wide	 Format	 →↔←	 TV/R
 ▼A-B	 Smart	 P+	 Ch +
 [-]/[Y]/[≡?]	 Media	 P-	 Ch -
 1	 1	 Up	 Up
 2	 2	 Down	 Down
 3	 3	 Right	 Right
 4	 4	 Left	 Left
 5	 5	 F/OK	 Ok
 6	 6	 Vol+	 Vol +
 7	 7	 Vol-	 Vol -
 8	 8	 Mute	 Mute
 9	 9	 Red/Surround	 Red
 0	 0	 Green	 Green
 -/[≡0]	 Guide	 Yellow/Bass	 Yellow
 CS	 Options	 Blue/Timer	 Blue

Original	Substitut	Original	Substitut
 Menu/[≡i]	 Menu	 TV	 AUX
 P↔P	 Pre Ch	 DVD	 SAT
 →↔←	 TV/R	 PLAY MODE	 REC MODE
 P+	 Ch +	 FF	 ■
 P-	 Ch -		 ⏮
 Up	 Up	 DISC NAV	 SOUND
 Down	 Down	 AD	 SETTINGS
 Right	 Right	 LIST	 DUAL
 Left	 Left	 SUBT	 OPT
 F/OK	 Ok	 PICTURE	 ECO
 Vol+	 Vol +	 SLEEP	 TV/R
 Vol-	 Vol -	 FORMAT	 3D
 Mute	 Mute	 E-MANUAL	 REPEAT
 Red/Surround	 Red	 ZOOM	 TIMER
 Green	 Green	 D.MENU	 TEXT
 Yellow/Bass	 Yellow	 ▲	 AV
 Blue/Timer	 Blue	 TOP MENU	 DISPLAY INFO



