



Original	Substitut
 Power	 Power
 Text	 Text
 [≡?]	 Shift + D. Menu
 Subtitles	 Subt
 [≡]	 Shift + Format
 [≡o]	 3D
 Size	 Eject
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Substitut
 Recall	 Pre Ch
 Source	 AV
 DTV	 TV/R
 EPG	 Guide
 ESG	 Smart
 Radio	 Media
 Audio I / II	 Dual
 Mute	 Mute
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Ch +
 P -	 Ch -
 AV Mode	 Shift + AV
 Surround	 Shift + Dual
 DTV Menu	 Options
 DTV Menu	 D. Menu
 List	 List



