







































































Original	Substitut	Original	Substitut
	Power		Power
	Source		AV / Input / RDS
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Shift + Back / Return
	Mute		Mute / Dimmer
	TV		TV/Radio /
	i		Info / Angle
	P+		CH+ / Page+
	P-		CH- / Page-
	Vol+		Vol+
	Vol-		Vol-
	OK		OK
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Menu		Menu / Home
	Q.Menu		D.Menu / Top
	Exit		Exit / Cancel / Clear
	Media		Display / Media
	Back		Back / Return
	Guide		Guide / EPG / -/-
	FAV		Fav / Marker / PC
	[≡]/Text		Text / Goto
	Netflix		Smart / List





Original	Substitut	Original	Substitut
www	Shift + Smart / List		
LANG. Lang	Audio / Lang I/II		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
[=]...	Sound / Title		
[-O-]	Picture / Format		
Yellow	Yellow / YouTube / Repeat		
Blue	Blue / Prime Video / Random		
Play	Play / Slow		
Pause	Pause / Step / Freeze		
>>	>> / Tune+		
<<	<< / Tune-		
Rec	Rec / Rec Mode		
Stop	Stop / Hold		

