


























































Original	Substitut	Original	Substitut
 Power	 Power	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 Home	 Smart
 3	 3	 G	 Guide
 4	 4	 i	 Info
 5	 5	 Back	 Back
 6	 6	 Exit	 Exit
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 Lang	 Dual	 OK	 Ok
 TXT	 Text	 Netflix	 Media
 Vol+	 Vol +	 YouTube	 Shift + Media
 Vol-	 Vol -	 *1	 Format
 Mute	 Mute	 Prime Video	 Shift + Smart
 Source	 AV	 Red	 Red

Original	Substitut	Original	Substitut
 P+	 Ch +	 TV	 AUX
 P-	 Ch -	 DVD	 REC MODE
 Home	 Smart	 SAT	 PLAY MODE
 G	 Guide	 AUX	 MUTE
 i	 Info	 SHIF	 TV
 Back	 Back	 DUAL	 SAT
 Exit	 Exit	 SUBT	 AUX
 Up	 Up	 AD	 MUTE
 Down	 Down	 SETTINGS	 TV
 Right	 Right	 LIST	 DVD
 Left	 Left	 DUAL	 SAT
 OK	 Ok	 SUBT	 AUX
 Netflix	 Media	 OPT	 MUTE
 YouTube	 Shift + Media	 ECO	 TV
 *1	 Format	 SOUND	 DVD
 Prime Video	 Shift + Smart	 AD	 SAT
 Red	 Red	 PICTURE	 AUX



