



























| Original | Substitut | Original | Substitut |
|--|---|---|--|
|  Power |  Power |  5 |  5 |
|  Red/↑ |  Red / Netflix / Search |  6 |  6 |
|  Green/↓ |  Green / APP / Repeat |  7 |  7 |
|  Yellow |  Yellow / YouTube / Repeat |  8 |  8 |
|  Blue |  Blue / Prime Video / Random |  9 |  9 |
|  [=] |  Text / Goto |  FAV |  Fav / Marker / PC |
|  [=x] |  Exit / Cancel / Clear |  0 |  0 |
|  EPG |  Guide / EPG / -/-- |  Tv/DTV |  TV/Radio / |
|  [*]/[■] |  Zoom / Size |  Vol- |  Vol- |
|  Screen |  Picture / Format |  Vol+ |  Vol+ |
|  Lang |  Audio / Lang I/II |  Mute |  Mute / Dimmer |
|  Subtitle |  Subtitle / EQ |  PR- |  CH- / Page- |
|  Sleep |  Sleep / Timer |  PR+ |  CH+ / Page+ |
|  1 |  1 |  Preset |  Smart / List |
|  2 |  2 |  Source |  AV / Input / RDS |
|  3 |  3 |  Info/[≡?] |  Info / Angle |
|  4 |  4 |  Swap/Recall |  Display / Media |



