






Original	Substitut	Original	Substitut
	Power		Power
	(*)		Subt
	[≡]		Text
	O		TV/R
	[ +]/◆		Info
	?		Options
	I-II/[≡i]		Dual
	16:9/+		Format
	(<>)/X		Exit
	Inst		Smart
	Input		AV
	P<P		Pre Ch
	P+		Ch +
	P-		Ch -
	Up		Up
	Down		Down
	Right		Right

Original	Substitut	Original	Substitut
	Left		Left
	Vol+		Vol +
	Vol-		Vol -
	Menu		Menu
	Red/Picture		Red
	Green/Audio		Green
	Yellow/Timer		Yellow
	Blue/Headphon		Blue
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9



