







































































Original	Substitut
 Power	 Power
 Mute	 Mute
 More	 Smart
 Code	 Media
 Code	 Shift + Media
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Zoom	 Eject

Original	Substitut
 OPT	 Options
 Red / <<	 Red
 Green / Stop	 Green
 Yellow /	 Yellow
 Blue / >>	 Blue
 Red / <<	 <<
 Green / Stop	 Stop
 Yellow /	 Play
 Yellow /	 Pause
 Blue / <<	 >>
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 TV/Radio	 TV/R
 Rec	 Rec









































Original		Substitut		Original		Substitut	
	Back		Back				
	Info		Info				
	Prog-		Ch -				
	Prog+		Ch +				
	Vol-		Vol -				
	Vol+		Vol +				
	TXT		Text				
	Still	+	Shift + Pause				
	Sound		Dual				
	PIP		Format				
	Menu		Menu				
	HDMI		AV				





Original	Substitut	Original	Substitut
PWR On/Off	 Power	OK Enter	 Ok
Mute	 Mute	Menu Right	 Right
Epg	 +  Shift + Guide	Exit	 Exit
Opt?	 Options	Menu Down	 Down
Subt.List	 Subt	Back	 Back
App	 Media	Audio	 Dual
Info	 +  Shift + Info	Volume+	 Vol +
Sleep Timer	 Sleep	CH/Page+	 Ch +
TV	 TV/R	Volume-	 Vol -
Video	 D. Menu	CH/Page-	 Ch -
Text	 Text	1. ?	 1
Zoom	 Eject	2abc	 2
TV/SAT	 AV	3def	 3
Menu	 Menu	4ghi	 4
Menu Up	 Up	5jkl	 5
Display	 Info	6mno	 6
Menu Left	 Left	7pqrm	 7








































Original	Substitut	Original	Substitut
8tuv	8 8	Lang./Rewind	<< <<
9wxyz	9 9	LNB F.Forward	>> >>
Guide Pilote	GUIDE Guide		
0/10	0 0		
FAV Pref.	PRE-CH Pre Ch		
Red	A Red		
Green	B Green		
Dev	LIST List		
Home Cinema	SMART Smart		
West	<< I<<		
Yellow	C Yellow		
Freeze	■ Stop		
Blue	D Blue		
On/Off	SHIFT + Power Shift + Power		
SAT Sky	SHIFT + AV Shift + AV		
H/V Play	▶ Play		
East	>> >>I		






























Original	Substitut	
PWR On/Off		Power
Mute		Mute
Epg	 + 	Shift + Guide
Sleep Timer		Sleep
Opt?		Options
App		Media
Info	 + 	Shift + Info
TV		TV/R
Video		D. Menu
Text		Text
Zoom		Eject
TV/SAT		AV
Menu		Menu
Menu Up		Up
Display		Info
Menu Left		Left
OK Enter		Ok

Original	Substitut	
Menu Right		Right
Exit		Exit
Menu Down		Down
Back		Back
Audio		Dual
Volume+		Vol +
CH/Page+		Ch +
Volume-		Vol -
CH/Page-		Ch -
1. ?		1
2abc		2
3def		3
4ghi		4
5jkl		5
6mno		6
7pqrm		7
8tuv		8





Original	Substitut	Original	Substitut
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

Original	Substitut	Original	Substitut
9wxyz	 9	East	 >>
Guide Pilote	 Guide	Lang./Rewind	 <<
0/10	 0	H/V Play	 Play
FAV Pref.	 Pre Ch	LNB F.Forward	 >>
Freeze	 Stop		
Scan/Setup	 +  Shift + Options		
Red	 Red		
Auth./DISEQC	 List		
Green	 Green		
Radio	 +  Shift + TV/R		
Yellow	 Yellow		
Blue	 Blue		
Home Cinema	 Smart		
Alt/16:9	 Format		
SAT Sky	 +  Shift + AV		
Dec/Pause	 Pause		
	 +  Shift + Exit		

