







































































Original	Substitut	Original	Substitut
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [◀▶]	 PICTURE FORMAT
 0	 0	 → ◻ ←	 SEARCH TV/R
 Recall	 FAV PRE-CH	 [i+] / [≡i]	 DISPLAY INFO
 Source	 TIMER AV	 Text / [≡] / [≡] []	 REPEAT TEXT
 Menu/DVD	 TOP MENU MENU	 [] / [▼]	 []
 Guide	 -/-- GUIDE	 [▶] / [I/II]	 PLAY MODE ▶
 [■][■■]	 ECO 3D	 [▶] / [I/II]	 SOUND DUAL


































































































Original	Substitut	Original	Substitut
 ◀◀ / [≡○]	 <<		
 ◀◀ / [≡○]	 SETTINGS OPT Options		
 ▶▶ / Subtitle	 AD SUBT Subt		
 ▶▶ / Subtitle	 >>		
 ▲	 HOME SMART Smart		
 ■ / [≡□]	 Stop		
 ◀◀◀ / [≡⇕]	 ZOOM ▲ Eject		
 ◀◀◀ / [≡⇕]	 ◀◀ I<<		
 ▶▶▶ / [⊖][≡X]	 >>> >>I		
 ▶▶▶ / [⊖][≡X]	 RETURN BACK Back		
 Red	 A Red		
 Green	 B Green		
 Yellow	 C Yellow		
 Blue	 D Blue		









































































Original	Substitut	Original	Substitut
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
  _ Menu/DVD	  Menu	  / [≡□]	 Stop
  - Exit/Back	  Exit	   / [≡⇅]	 Eject
  - Up	  Up	   / [≡⇅]	 I<<<
  Left	  Left	  / [⊙][≡X]	 >>>I
  OK	  Ok	  / [⊙][≡X]	 Back





Original	Substitut	Original	Substitut
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	- 7		7
	- 8		8
	- 9		9
	0		0
	Source		AV
	P+		Ch +
	P-		Ch -
	Vol-		Vol -
	Vol+		Vol +

Original	Substitut	Original	Substitut
	 / [v]		Pause
	 / I/II		Play
	 / I/II		Dual
	 / [≡●]		<<
	 / [≡●]		TV/R
	 / Subtitle		>>
	 / Subtitle		Subt
			Smart
	 / [≡□]		Stop
	 / [≡⇅]		Eject
	 / [≡⇅]		I<<
	 / [⊙][=X]		Back
	 / [⊙][=X]		>>I

