








































































































| Original | Substitut | Original | Substitut |
|---|---|---|---|
|  Power |  Power |  Text |  Text / Goto |
|  Mute |  Mute / Dimmer |  Source |  AV / Input / RDS |
|  Play/Pause/Hold |  Play / Slow |  Menu |  Menu / Home |
|  Pause |  Pause / Step / Freeze |  Up |  Up |
|  Stop/Size |  Stop / Hold |  ?? |  Info / Angle |
|  Rec Menu |  Rec / Rec Mode |  Left |  Left |
|  << |  << / Tune- |  OK |  OK |
|  >> / Cancel |  >> / Tune+ |  Right |  Right |
|  I<< / Index |  I<< / Preset- |  Exit |  Exit / Cancel / Clear |
|  >>I/Reveal |  >>I / Preset+ |  Down |  Down |
|  Nicam |  Audio / Lang I/II |  Back |  Back / Return |
|  Subtitle |  Subtitle / EQ |  Vol+ |  Vol+ |
|  Aspect |  Picture / Format |  List |  Smart / List |
|  Sleep |  Sleep / Timer |  CH+ / Page+ |  CH+ / Page+ |
|  Tv |  TV/Radio / |  Vol- |  Vol- |
|  Subpage |  D.Menu / Top |  Display |  Display / Media |
|  PC Auto |  Setup / OPT / |  CH- / Page- |  CH- / Page- |





| | Original | Substitut | | Original | Substitut |
|--|----------|---|---|---|---|
| | 1 |  1 | 1 |  DTV/Radio |  +  Shift + TV/Radio / Program |
| | 2 |  2 | 2 |  Media |  +  Shift + Display / Media |
| | 3 |  3 | 3 |  -/-- |  +  Shift + Guide / EPG / -/-- |
| | 4 |  4 | 4 |  Repeat |  +  Shift + Green / APP / Repeat |
| | 5 |  5 | 5 |  A-B |  +  Shift + Yellow / YouTube / Repeat A-B |
| | 6 |  6 | 6 | | |
| | 7 |  7 | 7 | | |
| | 8 |  8 | 8 | | |
| | 9 |  9 | 9 | | |
| | TVG |  Guide / EPG / -/-- | | | |
| | 0 |  0 | 0 | | |
| | FAV |  Fav / Marker / PC | | | |
| | Red |  Red / Netflix / Search | | | |
| | Green |  Green / APP / Repeat | | | |
| | Yellow |  Yellow / YouTube / Repeat | | | |
| | Blue |  Blue / Prime Video / Random | | | |
| | Freeze |  +  Shift + Pause / Step / Freeze | | | |

