

PINACLE  
DVD  
PIN001

Mandis Shop S.L.  
Sant Cugat del Vallès (Barcelona)  
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Off		V	Down	
MUTE			EXIT		
1	1		BACK		
2	2		VOL+	Vol+	
3	3		VOL-	Vol-	
4	4		INFO		
5	5		FAV(1S1)	Recall CH	
6	6		CH+	CH Up	
7	7		CH-	CH Down	
8	8		TEXT	Teletext	
9	9		< ?		
0	0		---		
VOID	<		TV/RADIO	TV	
MENU	Menu		CH+	Radio	
>PLAY	Play		SOURCE	AV	
PAUSE	Pause		V-FORMAT	Zoom	
[ STOP	Stop		WIDE		
oRECORD	Rec				
<<	<<				
>>	>>				
<<	←				
>>	→				
RFD	P				
GRFFN	L				
YELLOW	I				
BLLE					
MEDIA	>I				
EPG(GUIDE)	EPG				
OK	OK				
^	Up				
<	Left				
>	Right				