Mandis shop

RE91141

Original	Substitut	Original	Substitut
Power	Power	♫	5 / Audio
Mute	Mute		
Moon	1 / Setup		
Tv Arc.	4 / Mode		
Opt:	7 / Rep		
AUX	Source		
Vol +	V+		
Vol -	V-		
Bass+	+		
Bass-	-		
Voice+	Up		
Voice-	Down		
Play	Play / Band		
I<	I<		
>I	>I		
Videocamara	9 / Disp		
Playing	8 / A-B		

https://mandis.ca/ca/10897-896-comment-substituer-pr-Polk-RE91141.html