Original		Substitut	
	Power		Power
DISC	Red/Disc	A	Red
DOCK for iPod	Green/Dock for	B	Green
HELP	Yellow/Help	C	Yellow
SOURCE	Blue/♪ Source	D	Blue
DISC MENU POP-UP MENU	Pop-Up Menu/Disc Menu	TOP MENU MENU	Menu
	Home	HOME SMART	Smart
SOUND SETTINGS	III/Sound Settin	SOUND DUAL	Dual
BACK	Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
+	Vol +	+ VOL	Vol +
−	Vol -	VOL −	Vol -

Original		Substitut	
	Mute	MUTE	Mute
	Stop/Eject		Stop
	Play	PLAY MODE	Play
	Pause		Pause
	I<		I<<
	<<		<<
	>>		>>
	>I		>>I
1.@	1	1	1
2 ABC	2	2	2
DEF 3	3	3	3
4 GHI	4	4	4
5 JKL	5	5	5
MNO 6	6	6	6
7 PQRS	7	7	7
8 TUV	8	8	8
WXYZ 9	9	9	9

Original		Substitut	
0	0	0	0
TOP MENU	Top Menu	SHIFT +	TOP MENU MENU Shift + Menu
SUBTITLE	Subtitle	AD SUBT	Subt

Original	Substitut