Original		Substitut	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
Blu-ray	Blu-ray	2	2
DVD/ Blu-ray	DVD/Blu-ray	3	3
GAME	Game	4	4
TV AUDIO	Tv Audio	5	5
MEDIA PLAYER	Media Player	6	6
Bluetooth	Bluetooth	7	7
AM	AM	8	8
FM	FM	9	9
CHANNEL	CH+	CH +	Ch +
CHANNEL	CH-	CH –	Ch -
ECO	Eco	ECO 3D	3D
VOLUME	Vol +	VOL +	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute

Original		Substitut	
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
CH LEVEL	CH Level	SOUND DUAL	Dual
MODE	Mode	AD SUBT	Subt
MEMORY	Memory	FAV PRE-CH	Pre Ch
TUNE –	I<</Tune-		I<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause
TUNE +	Tune+/>>I		>>I
1	Quick Select 1	A	Red

Original	Substitut	Original	Substitut
QUICK 2 Quick Select 2	B Green		
SELECT 3 Quick Select 3	C Yellow		
4 Quick Select 4	D Blue		
SOUND < Sound Mode	<<		
D MODE Sound Mode >	>>		
D DELAY + Audio Delay+	HOME SMART Smart		
AUDIO – Audio Delay-	APP MEDIA Media		