Mandis shop

Yamaha FSR82

Original		Substitut	
	Power		Power
TV	TV	SEARCH TV/R	TV/R
BD/DVD	BD/DVD	D	Blue
COAXIAL	Coaxial	C	Yellow
ANALOG	Analog	A	Red
BLUETOOTH	Bluetooth	B	Green
BLUETOOTH STANDBY	Bluetooth	HOME SMART	Smart
CLEAR VOICE	Clear Voice	CLEAR EXIT	Exit
UNIVOLUME	Univolume	SOUND DUAL	Dual
AUDIO DELAY	Audio Delay	AD SUBT	Subt
MOVIE	Movie	1	1
MUSIC	Music	2	2
SPORTS	Sports	3	3
GAME	Game	4	4
TV PROGRAM	Tv Program	PROG SLEEP	Sleep
STEREO	Stereo	PICTURE FORMAT	Format
L	SRT Position L		Left

Original		Substitut	
C SRT POSITION	SRT Position C	OK	Ok
R	SRT Position R		Right
SUBWOOFER +	Subwoofer +	CH +	Ch +
SUBWOOFER −	Subwoofer -	CH −	Ch -
VOLUME +	Volume+	VOL +	Vol +
VOLUME −	Volume-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
CH LEVEL	CH Level	DISC NAV LIST	List
LEARN	Learn	APP MEDIA	Media

https://mandis.tv/a/Yamaha/1679-806-remote-substitution-for-Yamaha-FSR82-ZK77690.htm