Mandis shop

Pioneer CU-PD024

Original	Substitut	Original	Substitut
Open/Close	Eject	6	6
Play	Play	7	7
Stop	Stop	8	8
Pause	Pause	9	9
Repeat	Text	10	0
Random Play	TV/R	+10	Guide
Manual >>	>>	≧20	Pre Ch
<< Manual	<<	Clear	Exit
I << Track	I <<	Check	Smart
Track >>I	>>I	PGM	Sleep
< Index	Left	Time	AV
Index >	Right		
1	1		
2	2		
3	3		
4	4		
5	5		