Mandis shop

POLK AUDIO 981307102280K

Original		Substitut	
Power	Power	Power	Power
1	HDMI 1	1	1
2	HDMI 2	2	2
3	HDMI 3	3	3
TV	TV	PROGRAM TV/RADIO	TV/Radio /
Bluetooth	Bluetooth	BLUETOOTH 9	9
BASS +	Bass+	Up	Up
VOL +	Vol +	VOL +	Vol +
VOICE +	Voice+	CH + PAGE	CH+ / Page+
BASS -	Bass-	Down	Down
VOL -	Vol -	VOL -	Vol -
VOICE -	Voice-	CH - PAGE	CH- / Page-
Mute	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	EQ SUBTITLE	Subtitle / EQ
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
NIGHT	Night	CLEAR EXIT CANCEL	Exit / Cancel / Clear
3D	3D	FORMAT PICTURE	Picture / Format

Original		Substitut	
SPORT	Sport	RETURN BACK	Back / Return
VOLUME SURROUND -	Volume Surround-	SHIFT + VOL -	Shift + Vol -
VOLUME SURROUND +	Volume	SHIFT + VOL +	Shift + Vol +
BALANCE L	Balance L	◀	Left
BALANCE R	Balance R	▶	Right

https://mandis.tv/a/POLK-AUDIO-981307102280K-remote-substitute-POLK-AUDIO-981307102280K.htm