Mandis shop

193334-B10

Original		Substitut	
On Off	On / Off		Power
Sleep	Sleep	PROG SLEEP	Sleep
Volume	Volume +	+ VOL	Vol +
Volume	Volume -	VOL –	Vol -
CD	CD Play/Pause	PLAY MODE	Play
CD	CD Play/Pause		Pause
CD	CD Stop		Stop
FM	FM	+ CH	Ch +
AM	AM	CH –	Ch -
AUX	AUX	APP MEDIA	Media
Track Tune	Track - / Tune -		Left
Track Tune	Track - / Tune -		I<<
Track Tune	Track - / Tune -		<<
Track Tune	Track + / Tune +		Right
Track Tune	Track + / Tune +		>>
Track Tune	Track + / Tune +		>>I
Mute	Mute	MUTE	Mute

Original		Substitut	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

https://mandis.cat/ca/BOSE/1058485-91402-comandament-de-substitucio-per-BOSE-WAVE-RADIO-CD-White-193334-B10.html