Mandis shop

PackardBell STUDIO-ST

Original		Substitut	
POWER	Power		Power
	Home	HOME SMART	Smart
Back	←/Back	RETURN BACK	Back
Vol –	Vol-	VOL –	Vol -
Vol +	Vol+	+ VOL	Vol +
Video	Video	A	Red
Photo	Photo	B	Green
Music	Music	C	Yellow
Settings	☼/Settings	TOP MENU MENU	Menu
	Up		Up
Play / Enter	Enter	OK	Ok
Play / Enter	Play	PLAY MODE	Play
	Down		Down
	Left		Left
	Right		Right
	I<<		I<<
	Pause		Pause

Original		Substitut	
	>>I		>>I
	Stop		Stop
	<<		<<
	>>		>>
USB	USB	APP MEDIA	Media
OUTPUT	Output	TIMER AV	AV
Angle	Angle	SETTINGS OPT	Options
Info	Info	DISPLAY INFO	Info
Subtitle	Subtitle	AD SUBT	Subt
Audio EQ	Audio Eq	SOUND DUAL	Dual
Repeat	Repeat	REPEAT TEXT	Text
Zoom	Zoom	ZOOM	Eject
Mute	Mute	MUTE	Mute
Slide Show	[>]/Slide Show	ECO 3D	3D
Rotate	Rotate	PICTURE FORMAT	Format
Thumbnail	Thumbnail	SEARCH TV/R	TV/R

https://mandis.cat/ca/PackardBell/1062503-81559-comandament-de-substitucio-per-PackardBell-Studio-ST.html