Pairing the remote control
IF THE REMOTE DOES NOT POWER ON THE TV SET

METHOD 1

1.) Switch the TV on using the standby button on the TV set (not the remote control)
2.) Once switched on, press the standby button on the TV set once
3.) this will prompt the ‘pairing menu’ to appear, scroll through and highlight ‘Pair your remote’ by pressing the CH+/CH- TV button (scroll up/down function in the menu)
4.) then press the TV set’s standby button (OK function in the menu) to confirm your selection
5.) then with the remote control, press and hold the YELLOW and BLUE buttons for a few seconds, the power light will
blink 5 times to confirm the TV and remote control are paired.
IMPORTANT: Some TV sets require to press the GREEN and YELLOW buttons together for more than 3 seconds to pair remote control with your TV. Please read the TV’s manual anyway when usi

METHOD 2 (If the method 1 is not successful)

Using the buttons on the TV switch it on and select a Channel. Press the "Standby" button on the TV and a Menu will be shown listing "Pairing". Select this option and follow the on screen instructions. The Handset should now be paired to the TV.

Please refer to the TV manual for further details!